
Z80A Riser Socket
Z80A
SN74LS27N (Part 3)
SN74LS09N (Part 4)
SN74LS245N (Part 1)
245 'DIR' HIGH = A -> B
Note: BADDRCTRLOUT and BDATAOUT should be used on PCB connected to 'J1' for enable & direction of bus signals.
76000730 Rev A
Z80 Front Panel
Copyright 06/29/2021
Alec Ginsburg